


Hair dryer

Model : ALTEO
120V ALTEO CHROME



Original instructions

Read and save these instructions

Last update : 14/11/2014



3 RUE DES BRECHES – 44400 REZE - FRANCE
Tél. +33 (0)2 40 75 98 20
www.jvd.fr

TECHNICAL CHARACTERISTICS

120V 60Hz 1800W

Air flow : 70 and 115 m³/h


IP20 for the ALTEO hair dryer without any wall support

IP21 for the ALTEO CHROME version only

Electrical insulation : Class II – no need earthing

GENERAL POINTS

This hair dryer, specially designed for hotel use, is equipped with a rocker switch in the handle which prevents its use except when held in the hand. A soft pressure on the handle is needed to switch on the hair dryer. It has six operating levels.



IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **READ ALL INSTRUCTION BEFORE USING.**
- **KEEP AWAY FROM WATER.**

DANGER – As with most electrical appliances, electrical parts are electrically live even when the switch is off.

To reduce the risk of death by electrical shock:

- Always “unplug it” immediately after using.
- Do not use while bathing.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- If an appliance falls in to water, “unplug it” immediately. Do not reach into the water.

WARNING – To reduce the risk of burns, electrocution, fire, or injury to persons:

- An appliance should never be left unattended when plugged in.
- Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged in any manner or dropped into water. Return the appliance to a service center for examination and repair.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be locked. Keep the air openings free of lint, hair, and the like.
- Keep the cord away from hot or heated surfaces. Do not wrap the cord around the appliance.
- Never use while sleeping

- Never drop or insert any object into any opening or hose.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not place the heated unit directly on any surface while it is hot or still plugged in.
- Do not use an extension cord with this appliance.
- Do not direct hot air toward eyes or other heat-sensitive areas.
- Attachments may be hot during use. Allow them to cool before handling.
- Do not place appliance on any surface while it is operating or while switch is turned on.
- While using the appliance, keep your hair out of it. Keep your hair away from the air inlets.
- Do not operate with a voltage converter.

SAVE THESE INSTRUCTIONS

SPECIAL INSTRUCTIONS:

To avoid circuit overload, do not operate another high wattage appliance on the same circuit.

POLARIZED PLUG

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug fits in a polarized outlet only one way. If the plug does not fit into the outlet, reverse the plug and try again. If it still do not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

LINE CORD SAFETY TIPS

- Never pull or yank on the cord or the appliance.
- To insert plug, grasp it firmly and guide it into outlet.
- To disconnect appliance, grasp plug and remove it from outlet.
- Before each use, inspect the line cord for cuts and/or abrasion marks. If any are found, this indicates that the appliance should be serviced and the line cord replaced.
- Never wrap the cord tightly around the appliance, as this could place undue stress on the cord where it enters the appliance and cause it to fray and break.

DO NOT OPERATE APPLIANCE IF THE LINE CORD SHOWS ANY DAMAGE, OR IF APPLIANCE WORKS INTERMITTENTLY OR STOPS WORKING ENTIRELY.

HOW TO USE THE ALCI

This appliance is equipped with an ALCI (appliance leakage current interrupter) safety device specifically engineered for safety. It is for household use and may be plugged into a standard AC electrical outlet (ordinary household current).

HOW ALCI SAFETY DEVICE WORKS

The ALCI safety device in this unit is built into the plug. This device will make it is inoperable under some abnormal conditions, such as accidental immersion in water. **If the appliance is immersed in water, do not attempt to reset the ALCI safety device.**

The ALCI safety device is equipped with a test button so that its operation can be checked.

TO USE:

1. Press the Reset button on the ALCI safety device.
2. Plug your ALCI into an AC outlet then press the Test button.
3. The Reset button will pop out. This verifies the safety device is operating properly. If the Reset button does not pop out, do not use the unit. Return it immediately for service.
4. Press the Reset button to reactivate the ALCI safety device. Your hair dryer is ready for use.

Repeat this procedure every time you use the hair dryer to confirm that the safety device is ready is operational.

SPECIAL ATTENTION

- If the unit detects an electrical shock hazard, it will immediately shut off. To restore power, press the Reset button on the ESP/ALCI safety device to reactivate the circuit.
- This appliance is designed with a protective coating around the heating coils. When operating the first few times, you may notice momentary smoking when turning unit off. This represents no danger to the user and does not indicate a defect in the unit. This smoke should dissipate within a short time.

- Never block the air intake grille, as this will cause the unit to overheat. Should this happen, a built-in safety system will operate, and the unit will be shut off automatically. Turn the unit Off and clear any obstruction from the air intake grille. Wait 10 minutes before operating the appliance has sustained extensive damage. Do not try to repair it. See warranty for instructions.
- Never touch heating section as it may be hot and can burn you.
- To avoid possible scalp or hair burns, use very hot and fast setting only when hair is wet. Reduce to lower heat as hair dries.
- Do not keep appliance directed at one place; keep it in constant motion. This is especially important if drying a wig, which could be damaged by heat.
- For maximum airflow, hold dryer not closer to the head than six inches.
- To extend the life of the dryer, it is recommended to switch it to the coolest setting for a few seconds before shutting it off.
- Untwist the cord from time to time to avoid tangling.

HOW TO USE THIS HAIR DRYER

This hair dryer, specially designed for hotel use, is equipped with a rocker switch in the handle which prevents its use except when held in the hand. A soft pressure on the handle is needed to switch on the hair dryer. It has six operating levels.

AIR CONCENTRATOR: The air concentrator attaches to the end of the dryer barrel. It allows airflow to be directed on a small section hair at a time when hair is styled and shaped with a vent brush or comb. It can also be used to build body and fullness into fine, thin hair by directing the airflow against the natural growth pattern of the hair. Attachment will be hot during use. Allow it to cool before handling.

ION GENERATOR: This dryer is equipped with a built-in ion generator that automatically generates negative ions when the unit is operating. It is ideal for overall hair conditioning.

CARE AND CLEANING

This appliance requires permanently lubricated and will not require any additional lubrication. It contains no user serviceable parts.

CLEANING:

1. Unplug iron and let it cool completely before cleaning.
2. Wipe the surface with a soft, slightly damp cloth. Do not allow water or any other liquid get into appliance.

STORAGE:

- Unplug appliance and left it cool; store in a clean, dry place.
- Do not warp the cord around unit; it could cause the cord to wear prematurely and break.
- Do not put any stress on cord where it enters the handle, as it could cause cord to fray and possibly break.
- Never hang unit by the power cord.

Before returning unit for service: Clean the removable air intake grille as well as the fixed grille attached to the unit with a small brush or a vacuum cleaner brush attachment. Then try to operate unit again.

APPLIANCE GUARANTEED FOR 3 YEARS

Faulty connection or any damage resulting from wrongly usage or which is in contradiction to the instructions in this leaflet will render the guarantee void.

INSTALLATION

With the wall support, you can lock or not the supply wire.

